

Zubehör	„Digta 7“-Serie	Digta Station 447 Plus	Digta SonicMic II	Digta Soundbox 830
Kopfhörer				
Digta Headphone 565 Jack	•			
Digta Headphone 565 GBS	o	•		•
Digta Swingphone 568 Jack	•			
Digta Swingphone 568 GBS	o	•		•
Digta Earphone 957 Jack	•			
Digta Earphone 957 GBS	o	•		•
Digta Headphone 520	o	•		•
Mikrofon				
Digta DirectMic	•			
Fußschalter				
Fußschalter 536	o	•		o
Dockingstation				
Digta Station	•			
Digta W/LAN-Adapter	•			
USB Kabel				
USB Mini-Kabel	•			
USB Mini-Kurzkabel	•			
USB RollUp 991	•	•		
Barcode, RFID				
Digta Scan 407	•			
Digta Scan 404			•	
Akku				
Akkupack 962	•	•		
Sonstiges				
Digta Card 7	•			
Digta Autoladeadapter USB	•			

- kompatibel
- o Anschluss an Dockingstation

Zubehör

Digta Headphone 565	Digta Earphone 957	Digta Swingphone 568	Digta Headphone 520
Digta DirectMic	Fußschalter 536	Digta Station	Digta W/LAN-Adapter
USB Mini-Kabel	USB Mini-Kurzkabel	USB RollUp 991	Akkupack 962
Digta Scan 407	Digta Scan 404	Digta Card 7	Digta Autoladeadapter USB